



Модель	K			S		T		V			KS			KT			KV				KST		
	L1	L2	L3	L1	L2	L1	L2	L1	L2	L3	L1	L2	L3	L1	L2	L3	L1	L2	L3	L4	L1	L2	L3
AC10	-	-	-	-	-	28	48	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
AC20	41.5	43	43	41.5	43	41.5	61	41.5	43	43	41.5	43	57	41.5	61	43	41.5	43	43	43	41.5	61	57
AC30	55	57	57	55	57	55	76	55	57	57	55	57	74	55	76	57	55	57	57	57	55	76	74
AC40	72.5	75	75	72.5	75	72.5	99	72.5	75	75	72.5	75	95	72.5	99	75	72.5	75	75	75	72.5	99	95
AC50	-	-	-	93	96	93	124	93	96	96	-	-	-	-	-	-	-	-	-	-	-	-	-
AC60	-	-	-	98	101	98	129	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

Модель	KSV				KTV				KSTV				ST		SV			STV			TV		
	L1	L2	L3	L4	L1	L2	L3	L4	L1	L2	L3	L4	L1	L2	L1	L2	L3	L1	L2	L3	L1	L2	L3
AC10	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
AC20	41.5	43	57	43	41.5	61	43	43	41.5	61	57	43	41.5	61	41.5	43	57	41.5	61	57	41.5	61	43
AC30	55	57	74	57	55	76	57	57	55	76	74	57	55	76	55	57	74	55	76	74	55	76	57
AC40	72.5	75	95	75	72.5	99	75	75	72.5	99	95	75	72.5	99	72.5	75	95	72.5	99	95	72.5	99	75
AC50	-	-	-	-	-	-	-	-	-	-	-	-	93	124	93	96	124	93	124	124	93	124	96
AC60	-	-	-	-	-	-	-	-	-	-	-	-	98	129	-	-	-	-	-	-	-	-	-

Модель	K		S		V		KS		KV			KSV			SV	
	L1	L2	L1	L2	L1	L2	L1	L2	L1	L2	L3	L1	L2	L3	L1	L2
AC20A	41.5	43	41.5	41.5	43	43	41.5	57	41.5	43	43	41.5	57	43	41.5	57
AC30A	55	57	55	55	57	55	74	55	57	57	55	74	57	55	74	
AC40A	72.5	75	72.5	72.5	75	72.5	95	72.5	75	75	72.5	95	75	72.5	95	

**Примечание:** Размер А между осью блока и установочными отверстиями имеется в таблицах с размерами модулей